

# CHEF 775 / EZ 600 **CYCLE CHARTS**



## QUESTIONS?

CONTACT YOUR LOCAL DEALER  
FOR ASSISTANCE

 **blendtec**  
COMMERCIAL

## PROGRAMMING YOUR BLENDER

Changing profile configurations on the Chef Series and EZ blenders can be done by pressing a specific combination of 3 buttons. Within 10 seconds of the blender being switched on and ready for use, press each button (one after another) that matches the profile you want. The blender will operate with each button you press until the code is recognised.

### CHEF CODES

#### Multipurpose 1 Profile

Cancel. Small. Medium.



#### Multipurpose 2 Profile

Cancel. Medium. Large.



#### Multipurpose 3 Profile

Cancel. Large. +10.



### EZ CODES

#### Multipurpose 1 Profile

Small. Medium. Large.



#### Multipurpose 2 Profile

Medium. Large. Pulse.



#### Multipurpose 3 Profile

Large. Pulse. Small.



Once configured, the profile will be displayed for 1 second before returning to ready mode.

#### bt\_1 = Multipurpose 1:

best for blended coffee and pour over ice smoothies

#### bt\_2 = Multipurpose 2:


best for whole fruit and frozen fruit smoothies

#### bt\_3 = Multipurpose 3:


best for thick blends and milkshakes

## MULTIPURPOSE 1


### SMALL



### MEDIUM




### LARGE




## MULTIPURPOSE 2


### SMALL



### MEDIUM




### LARGE




## MULTIPURPOSE 3


### SMALL



### MEDIUM



### LARGE



## PULSE CYCLES

### MULTI 1



### MULTI 2



### MULTI 3



# CHEF 600 **CYCLE CHARTS**



## QUESTIONS?

CONTACT YOUR LOCAL DEALER  
FOR ASSISTANCE



 **blendtec**  
COMMERCIAL

## PROGRAMMING YOUR BLENDER

Congratulations on your purchase of the Chef 600. This chart guide will help you better understand the difference between each of the buttons on your new blender.

### MANUAL SPEEDS

The manual speed buttons will run a full cycle of X seconds at a constant low, medium, or high speed for 90 seconds.



LOW



MEDIUM



HIGH

### PULSE SPEEDS

The pulse buttons put the control in your hands. Press the low or high pulse to begin blending, release to stop.



LOW  
PULSE



HIGH  
PULSE

### CANCEL

The cancel button immediately stops the blend at any point during the manual speed cycles.



## MANUAL SPEEDS

LOW (90 seconds)



MEDIUM (90 seconds)



HIGH (90 seconds)



## PULSE SPEEDS

LOW PULSE



HIGH PULSE

